

3

Not all microwaves work exactly the same, so play with the timing until you get it just right. Try setting the microwave between 2:30-3:00 minutes and listen to the pops. Do not use popcorn button or setting on your microwave. It may take a while for things to get poppin'. Be patient and do not leave microwave unattended. Experiment a little - your microwave may cook the popcorn faster or slower than the 2:30-3:00 average! When the popping slows down to about 2 seconds apart, stop the microwave to prevent burning. If no popping occurs within 2 minutes, turn OFF microwave. Do not stop the microwave and start it again during the same batch.

RECIPES

Brown Sugar and Cinnamon Popcorn

Ingredients:

1 tbsp. brown sugar

tsp. ground cinnamon

Salt, to taste

In small bowl combine brown sugar and cinnamon. Prepare popcorn according to instructions, butter optional. Toss brown sugar mixture with warm, freshly popped popcorn.
Salt to taste.

Enjoy!

Lemon, Parmesan and Black Pepper Popcorn

Ingredients:

2 tsp. lemon zest

⅛ cup finely grated Parmesan cheese

Freshly grated black peppercorn, to taste

Fine grain sea salt, to taste

Combine lemon zest and Parmesan cheese in small bowl. Prepare popcorn according to instructions, butter optional. Toss mixture with warm, freshly popped popcorn. Add freshly grated black peppercorn and sea salt to taste.

7 41393 43253 4
EKPRE-4215 RED

Epoca INTERNATIONAL, LLC.
Boca Raton, FL 33487
Made in China

ecolution
Cook Well. Do Good.

Micro-Pop™
Popcorn Popper
For Microwave Use



Temperature safe glass

Dishwasher safe

Lid measures kernels and melts butter

1½ QT.

USE INSTRUCTIONS

READ WARNINGS and all instructions before first use!



1

Fill lid to fill line.



2

Pour the kernels into the bottom of the popper, place the lid on top of the popper. Optional - Add desired amount of butter to perforated lid and set on top of popper to allow butter to melt on top of popcorn.

Inside Cover | Outside Cover | Outside Cover | Inside Cover

Gate Fold | Gate Fold | Gate Fold

WARNING: Never microwave an empty popcorn popper. Damage to your microwave oven may result.

WARNING: Never leave microwave unattended while in use.

WARNING: If no popping occurs within 2 minutes, turn OFF microwave.

WARNING: Always use an oven mitt when removing popper from microwave.

WARNING: Hold hot popper away from your face and body.

WARNING: Do not bump glass microwave popper; glass is fragile and can break.

WARNING: Never attempt to remove the glass bowl from the plastic holder; they are not intended to separate.

WARNING: Always inspect glass for chips or cracks; do not use if chipped or cracked.

TIPS to getting your popcorn just right:

Not yielding perfect popcorn? Although our instructions are kitchen tested, microwave ovens can greatly vary.

1. Always use fresh popcorn kernels. Store your popcorn in an airtight container. Refrigeration is not recommended.
2. Not all microwaves are created equal. Microwaves will vary in wattage, and though many microwaves will pop your kernels just fine, there's always the few that want to be stubborn. If your precious popcorn is getting burnt when adding butter prior to popping, try adding the butter after all those kernels have transformed into beautiful puffed popcorn. Use a small, microwave-safe bowl to melt the butter and then use an oven mitt to pour it over your popcorn.
3. Stopping and starting your microwave during the cooking cycle is not recommended. Once you stop the microwave, the steam buildup in the center of the kernel, which causes the popcorn to pop, will cool off and never reach the desired temperature to re-pop. If you restart the microwave you also risk burning the already popped popcorn. Using the sound test is the best way to determine if your popcorn is done. If there are more than two full seconds between pops, it's time to stop.

SAFETY & CARE INSTRUCTIONS

- Always use an oven mitt.
- Wash product thoroughly before first use.
- After heating, lid will be hot. Escaping steam from lid can cause burns. When removing the lid use a pot holder or an oven mitt.
- Allow popper and lid to cool between batches.
- Clean popper and lid between batches.
- Let glass cool before hand washing or placing in the dishwasher.
- Easy to clean, popper and lid are both dishwasher safe.
- Keep out of reach of children.
- For microwave use only. Not for use on stovetop or any other source of heat.
- NEVER MICROWAVE AN EMPTY POPCORN POPPER. Damage to your oven may result.
- Do not use popcorn button or setting on your microwave.
- Only use popcorn popper in a clean, fully functioning microwave oven and in accordance with all safety instructions in your microwave oven's instruction manual.
- Never use popcorn popper in a microwave oven with missing, improperly functioning, or restricted turntable and turntable support. Damage to your microwave oven may result. The turntable must be in place and unrestricted so it can rotate.

Questions?
Contact Customer Service at customerservice@epoca.com

HOW MICROWAVES WORK

Microwave ovens heat by producing electromagnetic waves that cause water molecules in food to vibrate. This vibration produces heat. Microwaves do not "see" glass or plastic. Never place the popper in the microwave oven empty. Damage to your oven can occur.

IMPORTANT SAFETY INFORMATION

Read before use

It is very important to use fresh kernels that have not dried out and to store them in an airtight container to maintain their moisture. Popcorn kernels do not last indefinitely. Do not refrigerate kernels as this can dry them out. Do not use kernels past the manufacturer's expiration date.

WARNING! Dried out kernels can cause damage to your microwave and in extreme cases, even cause fires. Based on our kitchen tested time of 2½ minutes (without butter), average for most microwaves, popping should begin in 60-90 seconds. Understand your microwave by running a few tests with fresh kernels to establish the amount of time your microwave needs to pop the kernels optimally. Pay attention to the amount of time it takes for kernels to begin to pop. Use this as a guideline for future uses to avoid burning. **IF KERNELS HAVE NOT STARTED TO POP WITHIN 2 MINUTES STOP THE OVEN, DISCARD THE KERNELS AND OBTAIN NEW, FRESH KERNELS.**

Inside | Inside | Inside | Inside