

First, loosen caliper mounting bolts with tool. Loosen pin on top of caliper.



Remove existing brake pads from caliper.



Use tool to retract pistons back to its horizontal position.



Prepare new pair of TOP BRAKE disc brake pads. Assembled TOP BRAKE brake pads with spring. Insert them into the caliper.



Tighten the mounting bolts, then later the pin.



When brake pad installation is completed, check if rotor is aligned at center.