




FLAG POLE ASSEMBLE



1 *Install bracket in the desired location. Use the drywall anchors provided in the kit if necessary.*




2 *Attach the top piece of the flag pole to the bottom piece. Twist counter clockwise to tighten.*




3 *Install flag. Follow steps 4-6 that correspond with your flag type.*


POLE SLEEVE



4 *Loosen flag pole ring and temporarily remove it from flag pole.*




5 *Insert pole through pole sleeve flag and clip to the upper tag to secure the flag's position.*




6 *Reinsert the flag pole ring and clip the ring to bottom tag on the flag. Adjust the ring to the appropriate height and tighten the bolt.*


BRASS GROMMET




4 *Attach the upper clip to the upper grommet of the flag.*




5 *Attach the lower clip to the bottom grommet of the flag.*



6 *Loosen the flag pole ring and move the ring to the appropriate position. Tighten the bolt to secure the flag's position.*



7 *Adjust the bracket to your desired angle. Insert the pole and tighten the bracket bolt to secure the flag pole.*



8 *Fly Freely.*

SCAN ME

Visit https://g128store.com to see our full catalog of flags and banners.
Our flag guarantees 100% Customer Satisfaction.
Missing parts or have questions? Call or e-mail us at:

Phone: (630) 828-2147 **e-mail: info@G128store.com**



Good Quality for the Good Price

G128's flag kit features new "Tangle Free" technology, which uses sealed weather-proof ball bearings to ensure your flag will always hang properly. This premium flag kit utilizes white, black or silver finish and polymer hardware attachments to prevent rust and corrosion in all weather conditions.

Our premium flag kit also features a heavy-duty universal bracket that allows for direct mounting to homes or businesses. This bracket is made with a 13-position, 180-degree adjustable mount and a forged casting design. It is oven cured in powder coating to ensure a rust-free and oxidation-free product in all environments.

Complete kit includes everything needed for an easy, hassle-free installation.

Caring for Your Flag Kit

In the event of extreme weather conditions with wind exceeding 45 MPH, it is best to remove the flag and pole from the mount. Failure to protect your flag kit during such weather may result in damage to your flag.

KIT COMPONENTS

