
Grape Cutter



To disassemble:



1.Twist to remove bottom of Grape Cutter body from the top half



2. Grip the top half of the body by the base and, holding post in place, twist the plunger to remove



3. Remove spring and post



4. Clean and dry all parts thoroughly

To reassemble:

1. Place post into top half of body from the bottom and replace the spring
2. Grip the top half of the body by the base and, holding post in place, twist the plunger onto post
3. Replace the bottom half of the body by twisting until secure

⚠ WARNING: Product is very sharp. Handle with care when unpacking, using, cleaning and storing. Keep out of reach of children.

OXO BETTER GUARANTEE™ If you're not satisfied with your purchase, we want to hear about it. We will replace it or refund you, because we are here to make it better — guaranteed.

1% FOR THE PLANET OXO is committing 1% of our annual sales to support environmental nonprofits.

oxo.com

1 800 545 4411